
IMPORTANT SAFETY INSTRUCTIONS

Form 4657TE-05, 10-12
Supersedes Form 4657TE-05, 09-12

Operation Instructions for Scissors Lift Rack



HUNTER
Engineering Company

CONTENTS

1. IMPORTANT SAFETY INSTRUCTIONS	1
1.1 For Your Safety	1
1.2 Warning/Instruction Decal Placement	2
Warning / Operation Label Location	2
Runway Warning/Instruction Decals	3
Console Warning/Instruction Decals	4
1.2 Control Panel	7
1.3 Emergency Stop (Model RX45, RX45L and RX54 Only)	8
2. SPECIFICATIONS	9
2.1 Lift Capabilities	9
RX10 Series Lifts	10
RX12A Series Lifts	11
RX45 Series Lifts (Not Available in USA or Canada)	12
RX54 Series Lifts (Not Available in USA or Canada)	13
3. GETTING STARTED	15
3.1 Operator Responsibilities	15
3.2 Operator Qualifications	15
3.3 Operator Training	15
4. DETAILED OPERATION INFORMATION	17
4.1 Preparation	17
Lift Operation Safety Rules	17
4.2 Chocking the Wheels	18
4.3 Lift Operation	18
Raising the Lift	18
Lowering the Lift	19
Unlock and Lock Slip Plates with PowerSlide® Slip Plates (Optional Feature) ...	20
Inflation Station (Optional Feature)	20
4.4 Using the Workstep	22
4.5 Auxiliary Jacks	23
5. REGULAR MAINTENANCE	25
5.1 Maintenance Schedule	25
6. TROUBLESHOOTING	27
6.1 Troubleshooting Chart	27
APPENDIX	29
Maintenance/Training Documentation	29
Panel Control Drawing No. 220-44	30

1. IMPORTANT SAFETY INSTRUCTIONS

1.1 For Your Safety

Read all instructions.

Read and follow all caution and warning labels affixed to your equipment and tools. Misuse of this equipment can cause personal injury and shorten the life of the equipment.

Always use wheel chocks in front of and behind the left rear wheel after positioning a vehicle on the rack.

Use caution when jacking the vehicle.

ALWAYS WEAR OSHA APPROVED SAFETY GLASSES. Eyeglasses that only have impact resistant lenses are NOT safety glasses.

Wear non-slip safety footwear when operating equipment.

Do not wear jewelry or loose clothing when operating equipment.

Wear proper back support when lifting or removing wheels.

To reduce the risk of electrical shock, do not use on wet surfaces or expose to rain.

Verify that the appropriate electrical supply circuit is the same voltage and amperage ratings as marked on the aligner before operating.

To reduce the risk of fire, do not operate equipment in the vicinity of open containers of flammable liquids (gasoline).

Keep all instructions permanently with the unit.

Keep all decals, labels, and notices clean and visible.

To prevent accidents and/or damage to the aligner, use only Hunter recommended accessories.

Use equipment only as described in this manual.

SAVE THESE INSTRUCTIONS


1.2 Warning/Instruction Decal Placement

DANGER, WARNING, CAUTION, SAFETY INSTRUCTIONS, and other decals have been attached to the equipment for your safety.

Read and follow the decal instructions to prevent equipment damage and/or personal injury.

If any decal shown in this manual has been removed, is missing, or cannot be read, contact your local service representative for a replacement decal(s) or call Hunter Engineering Company at 1-800-448-6848. A new warning label kit (20-2480-1) may be ordered free of charge.

Warning / Operation Label Location



Runway Warning/Instruction Decals

Most of the runway warning/instruction decals are contained on one sheet of decals that has the groups of decals located near the turnplates, at the center and on the slip plates.

Composite 128-1307-3 has grouped decals for all RX10 (RX45) runways.

Composite 128-1305-3 has grouped decals for all RX12A (RX54) runways.



Decals near Turnplate Pockets



Decals near Center of Runway




Decals on Slip Plates (128-1307-3 with RX10 capacity shown)

Additional runway warning/instruction decals include work step decals and pit decals.



Decal on Work Step 128-1005-2



Decals on Pit Racks 128-978-2

Console Warning/Instruction Decals

The following warning/instruction decals are located on the lift control console.

CAUTION:

1. DO NOT RAISE OR LOWER LIFT WITH VEHICLE SUPPORTED ON JACKS.
2. ALWAYS SET BRAKE AND CHOCK A REAR WHEEL BEFORE OPERATING LIFT.
3. DO NOT EXCEED WEIGHT CAPACITY.
4. BE SURE OPERATING AREA IS FREE OF OBSTRUCTIONS AND PERSONNEL.
5. DO NOT OPERATE LIFT WITH COVERS REMOVED OR LOCKS DISABLED.
6. DO NOT ACTIVATE TRUCK MODE WITH A LOW GROUND CLEARANCE VEHICLE.

TO RAISE RACK

1. PUSH RAISE BUTTON TO RAISE RACK.
3. RELEASE RAISE BUTTON AT DESIRED HEIGHT.
4. LOWER LIFT ONTO LOCKS BY PUSHING LOWER BUTTON. ▼ NOT ON LOCKS AND ▲ MISMATCHED LOCKS LIGHTS SHOULD BE OFF.

TO LOWER RACK

1. PRESS THE RAISE BUTTON TO LIFT RACK OFF THE LOCKS (USUALLY ONE SECOND).
2. PRESS AND HOLD THE LOCK RELEASE BUTTON.
3. PRESS LOWER BUTTON TO LOWER LIFT TO DESIRED HEIGHT. RELEASE BOTH BUTTONS WHEN LIFT HAS REACHED DESIRED HEIGHT.
4. PRESS LOWER AGAIN TO LOWER ONTO LOCKS OR BASE. ▼ NOT ON LOCKS AND ▲ MISMATCHED LOCKS LIGHTS SHOULD BE OFF.

▲ MISMATCHED LOCKS LIGHT IS ON: PRESS RAISE UNTIL LIGHT IS OFF AND LOCKS ARE MATCHED AGAIN. (YOU WILL USUALLY HEAR ONE LOCK CLICK.) LOWER BUTTON IS DISABLED. RAISE THE LIFT TO RE-LEVEL.

▼ NOT ON LOCKS LIGHT IS ON (AND ▲ MISMATCHED LOCKS LIGHT IS OFF): CONTINUE PUSHING LOWER BUTTON UNTIL ▼ NOT ON LOCKS LIGHT GOES OFF.

128-1389-2

128-1389-2

128-1358-3
 DECAL - LIFT
 RACK CONSOLE



▲ DANGER

Lockout power before working on equipment.

128-310-2

DUTY CYCLE OF THIS LIFT IS 60 SEC ON AND 540 SEC OFF FOR A 10 MINUTE (600 SEC) CYCLE.

128-1165-2



▲ DANGER

IF CONNECTED TO A CIRCUIT PROTECTED BY FUSES, USE TIME-DELAY FUSE MARKED D.

Si connecté à un circuit protégé par des fusibles utiliser des fusibles à une action différée marquée D.

▲ WARNING

RISK OF EXPLOSION: THIS INSTRUMENT CABINET HAS INTERNAL ARCING OR SPARKING PARTS WHICH SHOULD NOT BE EXPOSED TO FLAMMABLE VAPORS. TO REDUCE THE RISK OF EXPLOSION, IT SHOULD NOT BE LOCATED IN A RECESSED AREA OR BELOW GARAGE FLOOR LEVEL.

ATTENTION: Ne pas utiliser à un niveau inférieur à celui du plancher du garage ou du sol.

128-198-2

Disconnect power before removing covers.

128-395-2



128-1358-3

CAUTION - TO PREVENT THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER. NO USER - SERVICEABLE PARTS INSIDE. REFER TO QUALIFIED SERVICE PERSONNEL.

128-158-2

SAFETY INSTRUCTIONS	If attachments, accessories or configuration modifying components that are located in the load path, affect operation of the lift, affect the lift electrical listing or affect intended vehicle accommodation are used on this lift and, if they are not certified for use on this lift, then the certification of this lift shall become null and void. Contact the participant for information pertaining to certified attachments, accessories or configuration modifying components.
www.autolift.org ©2007 by ALI, Inc. ALI / WLSIAO1	

128-1161-2

	18.08
	02.01
Eichung nur für Druckanzeige gültig! Druckart: Pe maximaler Anschlussdruck: 6 bar	
	
128-975-2	

128-975-2

Non-Incendive Circuits

Provides non-incendive circuit extensions for use in Class 1, Division 2, Group D, T4 or Class 1, Zone 2, Group IIA Hazardous (Classified) Locations when connected per Panel Control Drawing No. 220-45. 128-1179-2

128-1179-2

Intrinsically Safe Circuits

Provides intrinsically safe circuit extensions for use in Class 1, Groups D, Hazardous (Classified) Locations when connected per Panel Control Drawing No. 220-44. 128-1167-2













128-1167-2
















SAFETY WARNING LABELS FOR HINGED FRAME ENGAGING LIFTS

Lift Owner/User Responsibilities:

- A. This Safety Warning placard SHALL be displayed in a conspicuous location in the lift area.
- B. Use one of the mounting arrangements illustrated on back of this placard.
- C. These Safety Warning labels supplement other documentations supplied with the lift.
- D. Be certain all lift operators read and understand these labels, operating instructions and other safety related information supplied with the lift.

 WARNING	 WARNING	 WARNING
		
Position vehicle with center of gravity midway between adapters.	Remain clear of lift when raising or lowering vehicle.	Keep feet clear of lift while lowering.
 WARNING	 WARNING	 WARNING
		
Clear area if vehicle is in danger of falling.	Avoid excessive rocking of vehicle while on lift.	Keep clear of pinch points when lift is moving.



 CAUTION		<p>The messages and pictographs shown are generic in nature and are meant to generally represent hazards common to all automotive lifts regardless of specific style.</p> <p>Funding for the development and validation of these labels was provided by the Automotive Lift Institute, PO Box 33116 Indianapolis, FL 32893-3116.</p> <p>They are protected by copyright. Set of labels may be obtained from ALI or its member companies.</p> <p>©1994 by ALI Inc. 1/3-3/1-2 ALI/RL2000rev</p>
		
Lift to be used by trained operator only.	Power Unit: Secure placard near lift controls.	lift Control Console: Secure placard in an accessible location.
 CAUTION	 CAUTION	 CAUTION
		
Authorized personnel only in lift area.	Use vehicle manufacture's lift points.	Always use safety stands when removing or installing heavy components.
SAFETY INSTRUCTIONS	SAFETY INSTRUCTIONS	SAFETY INSTRUCTIONS
		
Read operating and safety manuals before using lift.	Proper maintenance and inspection is necessary for safe operation.	Do not operate a damaged lift.

128-368-2

128-368-2

1.2 Control Panel



NOTE

The “locked” and “free” slip plate controls located at the upper right corner are only present on lifts with the optional PowerSlide® feature.

NOTE

The Inflation Station controls located at the lower right corner are only present on lifts with the optional Inflation Station feature.

For RX10, RX10L and RX12A Series Lift Racks, intrinsically safe circuits provide intrinsically safe circuit extensions for use in Class 1, Groups D, hazardous (classified) locations when connected per Panel Control Drawing No. 220-44. Refer to Panel Control Drawing No. 220-44 on page 30.

1.3 Emergency Stop (Model RX45, RX45L and RX54 Only)

An emergency stop switch is located at the lower, right-hand corner of the console of the RX45, RX45L and RX54 Scissors Lift Rack.

Turning the emergency stop switch to the "OFF" position disconnects the power from the console.

Returning the emergency stop switch to the "ON" position restores power to console.

2. SPECIFICATIONS

2.1 Lift Capabilities

RX10 RX10L, RX12A, RX45 RX45L and RX54 lift specification listed on following pages.

All RX series lifts are intended for indoor use only. Use outdoors or where significantly exposed to the elements will void warranty and may cause premature component failure which may result in a hazardous condition.

RX10 and RX10L Series Lifts

RX10JT, RX10T-IS, RX10T-PS, RX10JFT, RX10FT-IS, RX10FT-PS, RX10LJT, RX10LT-IS, RX10LT-PS, RX10LJFT, RX10LFT-IS AND RX10LFT-PS

Maximum Lifting Weight:	4535 kg (10,000 pounds)
Operating Hydraulic Pressure:	3550 psi (max. @ full capacity)
Maximum Lifting Height:	1829 mm (72 inches)
Alignment Height:	All Lock Positions
Lifting Speed:	55 seconds
HI-Speed Lifting Speed	32 to 60 seconds (depending on load)
Lowering Speed:	50 seconds
HI-Speed Lowering Speed	29 seconds

Tread Width:

Minimum Inside Tires:	1016 mm (40 inches)
Maximum Outside Tires:	2235 mm (88 inches)

Maximum Wheel Base:

Surface-Mount RX10 Lifts: RX10JT, RX10T-IS AND RX10T-PS

4–Wheel Alignment:	4013 mm (158 inches)
2–Wheel Alignment:	4216 mm (166 inches)
General Service:	4343 mm (171 inches) (or 4639 mm (182 5/8 inches) with optional extended wheel stops)

Flush-Mount RX10 Lifts: RX10JFT, RX10FT-IS AND RX10FT-PS

4–Wheel Alignment:	4013 mm (158 inches)
2–Wheel Alignment:	4115 mm (162 inches)
General Service:	4241 mm (167 inches)

Surface-Mount RX10L Lifts: RX10LJT, RX10LT-IS AND RX10LT-PS

4–Wheel Alignment:	4013 mm (158 inches)
2–Wheel Alignment:	4547 mm (179 inches)
General Service:	4673 mm (184 inches) (or 4969 mm (195 5/8 inches) with optional extended wheel stops)

Flush-Mount RX10L Lifts: RX10LJFT, RX10LFT-IS AND RX10LFT-PS

4–Wheel Alignment:	4013 mm (158 inches)
2–Wheel Alignment:	4445 mm (175 inches)
General Service:	4572 mm (180 inches)

RX12A Series Lifts

RX12AJT, RX12AT-PS, RX12AT-IS, RX12AJFT, RX12AFT-PS, RX12AFT-IS

Maximum Lifting Weight:	5443 kg (12,000 pounds)
Operating Hydraulic Pressure:	3550 psi (max. @ full capacity)
Maximum Lifting Height:	1803 mm (71 inches)
Alignment Height:	All Lock Positions
Lifting Speed:	55 seconds
HI-Speed Lifting Speed	32 to 60 seconds (depending on load)
Lowering Speed:	50 seconds
HI-Speed Lowering Speed	29 seconds

Tread Width:

Minimum Inside Tires:	1016 mm (40 inches)
Maximum Outside Tires:	22235 mm (88 inches)

Maximum Wheel Base:

Surface-Mount RX12A Lifts: RX12AJT, RX12AT-IS AND RX12AT-PS

4-Wheel Alignment:	4013 mm (158 inches)
2-Wheel Alignment:	4547 mm (179 inches)
General Service:	4673 mm (184 inches) (or 4969 mm (195 5/8 inches) with optional extended wheel stops)

Flush-Mount RX12A Lifts: RX12AJFT, RX12AFT-IS AND RX12AFT-PS

4-Wheel Alignment:	4013 mm (158 inches)
2-Wheel Alignment:	4445 mm (175 inches)
General Service:	4572 mm (180 inches)

RX45 and RX45L Series Lifts (Not Available in USA or Canada)

RX45, RX45-IS, RX45F, RX45F-IS, RX45L, RX45L-IS, RX45LF AND RX45LF-IS
(Listed models do NOT include voltage suffix, such as -2-1-6E or -4-3-UE)

Maximum Lifting Weight:	4535 kg. (10,000 lbs)
Operating Hydraulic Pressure:	3550 psi (max. @ full capacity)
Maximum Lifting Height:	1829 mm (72 inches)
Alignment Height:	All Lock Positions
Lifting Speed:	55 seconds
Lowering Speed:	50 seconds

Tread Width:

Minimum Inside Tires:	1016 mm (40 inches)
Maximum Outside Tires:	2235 mm (88 inches)

Maximum Wheel Base:

Surface-Mount RX45 Lifts: RX45 AND RX45-IS

4–Wheel Alignment:	4013 mm (158 inches)
2–Wheel Alignment:	4216 mm (166 inches)
General Service:	4343 mm (171 inches) (or 4639 mm (182 5/8 inches) with optional extended wheel stops)

Flush-Mount RX45 Lifts: RX45F AND RX45F-IS

4–Wheel Alignment:	4013 mm (158 inches)
2–Wheel Alignment:	4115 mm (162 inches)
General Service:	4241 mm (167 inches)

Surface-Mount RX45L Lifts: RX45L AND RX45L-IS

4–Wheel Alignment:	4013 mm (158 inches)
2–Wheel Alignment:	4547 mm (179 inches)
General Service:	4673 mm (184 inches) (or 4969 mm (195 5/8 inches) with optional extended wheel stops)

Flush-Mount RX45L Lifts: RX45LF AND RX45LF-IS

4–Wheel Alignment:	4013 mm (158 inches)
2–Wheel Alignment:	4445 mm (175 inches)
General Service:	4572 mm (180 inches)

RX54 Series Lifts (Not Available in USA or Canada)

RX54, RX54IS, RX54F AND RX54FIS

(Listed models do NOT include voltage suffix, such as -215E, -216E or -435E)

Maximum Lifting Weight:	5400 kg (12,000 pounds)
Operating Hydraulic Pressure:	3550 psi (max. @ full capacity) 24, 476 kpa (max. @ full capacity)
Maximum Lifting Height:	1803 mm (71 inches)
Alignment Height:	All Lock Positions
Lifting Speed:	55 seconds
HI-Speed Lifting Speed	32 to 60 seconds (depending on load)
Lowering Speed:	50 seconds
HI-Speed Lowering Speed	29 seconds
Tread Width:	
Minimum Inside Tires:	1016 mm (40 inches)
Maximum Outside Tires:	2235 mm (88 inches)
Maximum Wheel Base:	
Surface-Mount RX54, RX54IS	
4–Wheel Alignment:	4013 mm (158 inches)
2–Wheel Alignment:	4547 mm (179 inches)
General Service:	4673 mm (184 inches) (or 4969 mm (195 5/8 inches) with optional extended wheel stops)
Flush-Mount RXF54, RX54FIS	
4–Wheel Alignment:	4013 mm (158 inches)
2–Wheel Alignment:	4445 mm (175 inches)
General Service:	4572 mm (180 inches)

3. GETTING STARTED

3.1 Operator Responsibilities

Read and thoroughly familiarize yourself with these instructions before operating the lift.

The operator shall operate the automotive lift only after being properly instructed or trained as outlined in Section 3.3.

The operator shall use all applicable safety features provided on the automotive lift, and operate the lift in accordance with the instructions furnished with the lift.

The operator of the lift shall be responsible for maintaining the cleanliness and orderliness of the lift and its surroundings so the lift may be safely operated in accordance with the instructional and safety materials furnished with the lift.

The lift owner or employer shall take all appropriate steps to follow the recommended inspection procedures, but in no event shall the lift operator fail to inspect or take notice of the procedures in the maintenance tables in Section 5. All procedures shall be completed within the time frame noted in the table.

3.2 Operator Qualifications

To avoid personal injury, only qualified personnel with a clear understanding of lift operations should be allowed to operate and perform maintenance on this equipment.

The operator must be capable of reading and understanding all of the provided instructions and the Automotive Lift Institute publication, "Lifting It Right," "Safety Tips," and "Warning Labels."

If inspection of the equipment finds components requiring replacement, contact your factory authorized Service Representative.

3.3 Operator Training

The owner or employer shall ensure that operators of automotive lifts are instructed in the safe use of the lift using all of the provided instructions and the Automotive Lift Institute publication: "Lifting It Right," "Safety Tips," and "Warning Label."

The owner or employer shall display these materials in a conspicuous location in the lift area.

The owner or employer shall appropriately document operating training. A Maintenance/Training documentation form has been provided in the Appendix.

4. DETAILED OPERATION INFORMATION

4.1 Preparation

Lift Operation Safety Rules

Read and familiarize yourself with these instructions before operating lift.

Do not operate an improperly functioning lift.

Do not attempt to use a lift for any purposes other than lifting vehicles.

Properly chock vehicle before operating lift.

Make sure lift is clear of personnel and obstructions before operating.

Do not operate a lift with anyone on or under the lift structure.

Watch lift and vehicle when operating.

Do not operate a lift with anyone in the vehicle.

Always set lift on safety lock latches before working on the vehicle.


Do not operate the vehicle while it is raised on the lift.

Do not operate a lift if the vehicle to be lifted is supported on jacks or any other auxiliary devices.

Do not install or use any unauthorized lifting devices or accessories.

Perform regular maintenance in accordance with instructions in Section Five.

NOTE:	It is advisable to use a second person as a “spotter” to give visual assistance to the driver when approaching and driving onto and off the runways.
--------------	--

 CAUTION:	For safety, proper chocking of vehicle wheels is necessary to prevent the vehicle from rolling while positioned on elevated runways.
---	--

4.2 Chocking the Wheels

Adjust the turn plates (with lock pins installed) to match the tread width of the vehicle.

Drive the vehicle onto the rack, place the transmission in PARK, and SET the emergency brake.

Place a wheel chock, 22-442-2, at the front and rear of the left rear wheel.



LEFT REAR WHEEL SHOWN

Leave the wheel chocks in place while elevating the lift, performing service operations on the vehicle, and while lowering the lift.

After lowering the lift, remove the wheel chocks from the front and rear of the tire before moving the vehicle.

4.3 Lift Operation

Raising the Lift

Check the lift and immediate area for obstructions and remove any that are found.

Verify that the turnplates and runway slip plates are locked in place.

⚠ WARNING: Do NOT operate lift with jacks in use. Serious injury may result if the lift is raised or lowered with a vehicle supported by jacks.

Verify "POWER" light is illuminated, indicating electrical power is supplied to console and the power switch located on the back of the console is in the "ON" position.

Depress and hold the "RAISE" button. The pump will begin to operate, raising the lift.

⚠ CAUTION: Listen for the sound of the mechanical locks passing over their detents. If the sound is not heard, release the "RAISE" button and refer to the troubleshooting section of this manual.

Release the "RAISE" button when the lift reaches the desired height. The pump will shut off and the lift will stop.


Press and hold the "LOWER" button until the lift stops lowering, mechanical locks engage and the "NOT ON LOCKS" light is no longer illuminated.

NOTE: When “MISMATCHED LOCKS” message is illuminated, the “LOWER” button is disabled.

If “MISMATCHED LOCKS” message is illuminated, raise the lift to re-level and correct mismatched lock condition.

Press “RAISE” button until “MISMATCHED LOCKS” message is no longer illuminated (usually hear one lock click) and locks are matched again.


Again lower lift to engage mechanical locks.


 **CAUTION:** Ensure mechanical locks are fully engaged before proceeding to service the vehicle.

Lowering the Lift

Remove all obstacles from under the rack and runways.


Be certain the vehicle is resting firmly on the runways with chocks both in front of and behind the left rear wheel.

 **WARNING:** Do NOT operate lift with jacks in use. Serious injury may result if the lift is raised or lowered with a vehicle supported by jacks.

 **CAUTION:** Ensure the jacks are in the stored position, before completely lowering the lift.

Verify that the turnplates and runway slip plates are locked in place.

Depress and hold the “RAISE” button until lift rises off locks (approx. 1 inch (25 mm)).

 **CAUTION:** Ensure the optional leveling legs, if so equipped, are pivoted into the horizontal storage position.

Depress and hold the “LOCK RELEASE” button to disengage the locks.

While continuing to hold the “LOCK RELEASE” button, depress the “LOWER” button until the lift reaches the desired height.

Release both buttons when the lift reaches the desired height.

Depress and hold the “LOWER” button until the mechanical locks engage and the “NOT ON LOCKS” message goes away.

If “MISMATCHED LOCKS” message appears, raise the lift to re-level and correct mismatched lock condition.

Press “RAISE” button until “MISMATCHED LOCKS” message goes away (usually hear one lock click) and locks are matched again.

Again lower lift to engage mechanical locks.

NOTE: On lifts with PowerSlide, the slip plates automatically lock as the lift is lowered to the floor.

If the lift is being lowered completely, ensure the lift rack is resting fully on the floor before removing the wheel chocks.

Remove all wheel chocks.

Before removing vehicle from lowered lift, verify that the turnplates and runway slip plates are locked in place. Use lock pins if optional PowerSlide feature is not present. Carefully drive the vehicle off the runways.

Unlock and Lock Slip Plates with PowerSlide® Slip Plates (Optional Feature)

Keypad controls for the PowerSlide® slip plates are located on the upper, right side of the control panel.




With the lift at alignment height, press the image of the free slip plate or the locked slip plate to control the status of slip plates.

Status of slip plate is indicated by the glowing green LED located next to the image of the free slip plate or the locked slip plate.

NOTE: Slip plates will automatically lock as the lift is lowered to the floor. Slip plates will also automatically lock if the console loses electrical power.

Inflation Station (Optional Feature)

Keypad controls for the Inflation Station system are located in the lower, right section of the control panel.



Tire Pressure Adjustment

NOTE: Inflation station provides pressure adjustment for inflated tires. Initial tire pressure must be at least 8 PSI (0.6 bar).

Connect the air line(s) to the vehicle.



Use the adjustment control arrows on either side of the pressure displays to set the desired tire pressure for each axle.

Each tire has a LED indicator to provide status information:

RED – Air line disconnected during adjustment.

YELLOW – Tire pressure currently adjusting.

GREEN – Tire pressure is adjusted correctly.

After each status indicator has turned green, the air lines may be removed from the vehicle.

The “Stop Fill” button may be pressed at any time to immediately stop tire pressure adjustments.

4.4 Using the Workstep

NOTE: Worksteps are not provided for pit installations. If worksteps are used in a pit installation, each workstep must be removed from the rack before lowering the rack into pit.

The lift is supplied with portable worksteps that fits into the side of the rack through specially designed cutouts.

When using a workstep, always ensure the workstep is fully engaged and locked into the cutout in the side of the runway.

Always use two hands to install the workstep as follows:

Align the workstep hanger brackets with the cutouts in side of lift rack.

Push the workstep forward and down until the locks “snap” into place.

Note the photos below:



Correct Installation, Fully Inserted - The workstep hanger brackets have been fully inserted through the cross-cutout and are locked in place.



Improper Installation, Partially Inserted - The workstep is only partially through the cutouts. The yellow decal indicates the workstep is not locked onto the side of the runway. In this unsafe condition, the step can easily be pulled out of the runway. Push step forward and down until locked.

CAUTION: Do not use a workstep that is improperly installed. If the yellow decal indicates the workstep is not locked, the step can pull out. Resulting injuries from falling are possible.

Check the stability of the workstep by pushing down on the stepping surface before standing on it.


When using the workstep, always use a safe, sturdy, OSHA-approved two-rung stepladder, as intermediate steps to mount the workstep.

CAUTION: If using more than one portable workstep on one side of the lift do not attempt to step across or jump from one step to another. Serious injury could result from improper usage of the worksteps.

To remove workstep, simultaneously pull back tabs to disengage locks.

4.5 Auxiliary Jacks

Refer to jack operation instructions if your lift is so equipped.

 **CAUTION:** The jacks can not be located closer than 60 inches of each other. Damage to lift, jack or vehicle shifting may occur.

5. REGULAR MAINTENANCE

5.1 Maintenance Schedule

NOTE: For lockout / tagout instructions, refer to ANSI Z244.1.

Maintenance is to be performed by shop employee or trained lift service personnel.

Worn, damaged or broken parts need replaced with parts approved by the original equipment manufacturer or with parts meeting original manufacturer specifications.

MAINTENANCE SCHEDULE	PERFORM THE FOLLOWING MAINTENANCE
DAILY	<p>Check the mechanical lock mechanism in each runway.</p> <p>Clean any debris from roller wheel tracks located at rear of base frames.</p> <p>Clean any debris from the locks. Keep lock area clean and free of debris at all times.</p> <p>Check the hydraulic cylinders, hoses, and fittings for leaks. Leaks MUST be corrected immediately.</p> <p>Check condition of hoses. Worn or frayed hoses MUST be replaced immediately.</p> <p>Check the fluid level in the tank with the lift lowered completely. When adding hydraulic fluid (Dexron III), the lift MUST be lowered completely.</p> <p>Check and lubricate rear ramp pivots with SAE 30 oil.</p> <p>Check base frame anchor bolts for tightness.</p>
WEEKLY	<p>Check the turn plates and rear slip plates for smooth and easy operation.</p> <p>Clean by blowing out with compressed air. Disassembly is NOT required. CAUTION: Always wear eye protection when using compressed air.</p>
MONTHLY	<p>Clean and lubricate the tracks of the rub blocks. Rub blocks are located at the base and under the runways. Wipe clean and apply NLGI grade 2 bearing grease to running surfaces and side surfaces of tracks.</p> <p>Do NOT lubricate turn plates or slip plates.</p>
EVERY TWO YEARS	<p>Change hydraulic fluid. Use 13.25 liters (3-1/2 gallons) of Dexron III transmission fluid.</p> <p>During each fluid change, replace the filter located on suction line, clean any metal particles on the magnet located on return line, and remove any sediment from bottom of reservoir.</p>

6. TROUBLESHOOTING

6.1 Troubleshooting Chart

PROBLEM	POSSIBLE CAUSE	SOLUTION
Lift does not operate (LED is not flashing).	<p>“POWER” switch in OFF position.</p> <p>Circuit breaker or fuse blown in shop power panel.</p> <p>Self-test failure.</p> <p>Electrical malfunction in control console.</p> <p>Hydraulic system malfunction.</p>	<p>Rotate switch to the ON position.</p> <p>Locate shop power panel and restore power.</p> <p>If overload repeats due to lift operation, contact factory service representative.</p> <p>Contact factory service representative.</p> <p>Contact factory service representative.</p> <p>Contact factory service representative.</p>
“RAISE” button depressed, motor runs but lift will not rise to full height.	<p>Low hydraulic fluid level in reservoir.</p> <p>Overhead obstruction to vehicle.</p> <p>Voltage supply is low.</p> <p>Hydraulic system malfunction.</p>	<p>Lower lift.</p> <p>Turn OFF shop power.</p> <p>Check hydraulic fluid level and fill. Determine reason for low fluid level.</p> <p>Lower lift and remove obstruction.</p> <p>Contact factory service representative.</p> <p>Contact factory service representative.</p>
“RAISE” button depressed, motor runs but lift does not move.	<p>Vehicle is beyond capacity: 10,000 lb on RX10/RX10L series 12,000 lb on RX12A series 4,535 kg on RX45/RX45L series 5,443 kg on RX54 series</p> <p>Electrical/Hydraulic controls malfunction.</p>	<p>Do not attempt to lift vehicles in excess of lift capacity.</p> <p>Contact factory service representative.</p>
Runways continue to rise after “RAISE” button is released.	Electrical control malfunction.	<p>Turn the “POWER” switch OFF.</p> <p>Turn OFF shop power.</p> <p>Contact factory service representative.</p>
“RAISE” button depressed, but no sound of mechanical locks passing over detents.	Lock mechanism binding.	Clean and lubricate lock mechanism pivot points. If condition remains, contact factory service representative.
Safety ratchet not fully engaged.	Misalignment of ratchets.	Contact factory service representative.

Troubleshooting (continued)

PROBLEM	POSSIBLE CAUSE	SOLUTION
"LOWER" button depressed, lift does not move.	Mechanical locks engaged.	Raise the lift off the locks. Press and hold the "LOCK RELEASE" and "LOWER" buttons to lower the lift.
	When "MISMATCHED LOCKS" message is present, "LOWER" button is disabled.	Raise lift until "MISMATCHED LOCKS" message is no longer illuminated
	Hydraulic system malfunction.	Contact factory service representative.
Lift will not raise or lower. LED flashes twice (Error code 2), pauses and repeats 5 times.	The Lift has exceeded maximum allowed out-of-level limit for normal operation.	Let the error code clear (The error code will clear after 6 flash cycles). Depress the "RAISE" or "LOWER" button to allow the lift to try to correct the out-of-level condition.
Lift will not raise or lower. LED flashes three times (Error code 3), pauses and repeats.	The lift did not correct the out-of-level condition after reporting an error code 2 above.	Turn "POWER" switch OFF and back ON. Let error code 2 clear, then lower the lift onto the same locks or the floor to regain level condition.
Lift will not raise or lower. LED flashes four times (Error code 4), pauses and repeats.	The Lift has exceeded maximum allowed out-of-level limit for corrective operation (4 inches out of level).	Lift controls are unresponsive. Contact factory service representative.
Lift will not raise or lower. LED flashes five times (Error code 5), pauses; repeats.	Sensor calibration error or lost sensor signal.	Contact factory service representative.
Lift will not raise or lower. LED flashes six times (Error code 6), pauses and repeats.	Control board is not properly calibrated.	Contact factory service representative.
"LOWER" button depressed, lift lowers slightly, then stops.	Locks not completely disengaged.	Raise the lift slightly then press the "LOCK RELEASE" button and the "LOWER" button simultaneously.
	Velocity fuse tripped.	Contact factory service representative.
	Electrical/Hydraulic controls malfunction.	Contact factory service representative.
Lift stops operating.	Two buttons pressed simultaneously.	Turn "POWER" switch OFF and back ON.
	Button pressed at power up.	Turn "POWER" switch OFF and back ON.
	Exceeded expected operational time.	Do not attempt to continually operate pump with lift in fully elevated position. Do not attempt to lift vehicles in excess of lift capacity

APPENDIX


Maintenance/Training Documentation

A thorough record of each maintenance/training procedure must be prepared by the owner/employer. Use the following documentation sheet.

NOTE:	Make several copies of this documentation sheet before beginning entries are made.
-------	--

Type of Maintenance/ Training	Date Performed	Performed By: (Initials)	Type of Maintenance/ Training	Date Performed	Performed By: (Initials)

Panel Control Drawing No. 220-44



NOTES:

1. INSTALL IN ACCORDANCE WITH ARTICLE 504 OF THE NATIONAL ELECTRICAL CODE.
2. MAXIMUM CABLE LENGTH IS 43 FEET OF HUNTER P/N: 38-970-2 THE I.S. BARRIER WILL NOT OPERATE PROPERLY WITHOUT AN EFFECTIVE GROUND. BE SURE THAT THE BARRIER IS DIN RAIL MOUNTED.
4. WARNING -- SUBSTITUTION OF COMPONENTS MAY IMPAIR INTRINSIC SAFETY.
5. MAX CAPACITANCE = 60pF/FT. MAX INDUCTANCE = .20 uH/FT.

SHT OF THIRD ANGLE PROJECTION		HUNTER Engineering Company 1250 HUNTER DRIVE BRIDGETON MISSOURI 63044	
NAME WIRING-CONTROL/IS BARRIER SYS		MATERIAL	FINISH
HEAT TREATMENT		SCALE NONE	
DR. D. SAIL 2019 11-01-00		ENGINEERED BY	
SUPERSEDES		SUPERSEDED BY	
PART NO. 220-44			

C 3-B-12	ADDED 125-452-1	2012-1120
B 1 23-88	ADDED 125-421-1	
A 2-21-88	REVISED DESIGN	1203-34
UNLESS OTHERWISE SPECIFIED, DIMENSIONS ARE IN INCHES. TOLERANCES: 2 PL. DEC. .015, 2 PL. DEC. .005 ANGLES: 2°		
THIS DRAWING IS THE PROPERTY OF THE HUNTER ENGINEERING COMPANY. IT IS NOT TO BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, INCLUDING PHOTOCOPYING, RECORDING, OR BY ANY INFORMATION STORAGE AND RETRIEVAL SYSTEM, WITHOUT THE WRITTEN PERMISSION OF THE COMPANY. SEE DRAWING FOR OTHER NOTES.		
ROUTING R I OC A PD BP ME W P PJ		
INTERPRET DIMENSIONS AND TOLERANCES PER ASME Y14.5 2009		